


TWO HAND STATION

TABLE 2



NOTE: CONNECTIONS TO X1/X2/X3/X4 MUST BE SCREENED
4 CORE WITH OVERALLSCREENING IS ACCEPTABLE

INSTALLATION NOTES

- 1 Assemble the F-SERIES control system as required (See F-SERIES installation guide for full details)
- 2 Connect the Two Button station as shown in table 2

BUTTON 1 & 2	CONTACT 1	To Two Hand Override Module
BUTTON 1 & 2	CONTACT 2	In parallel across the reset button contact
BUTTON 1 & 2	CONTACT 3	In parallel across each start button

IMPORTANT: Ensure that Button 1 & Button 2 (Contact 2) are connected in parallel across the reset button to ensure the correct operation

